



268.0251.i.1

INSIDE OF GLASS SURFACE

- 1. Dip transfer in water for 10 sec.**
- 2. Apply colored side to glass. Smooth down pressing with a straight edge or hand from center to edge to remove water and air bubbles.**
- 3. Rewet paper backing which will release from color film then slide paper away from design and remove.**
- 4. Wash back of transfer with water. Let dry.**

FOR WOOD OR METAL SURFACES

- 1. Dip transfer in water for 10 sec.**
- 2. Remove from water and set aside for 30 sec.**
- 3. Slide transfer off paper until it projects about one quarter inch.**
- 4. Place projecting edge in position and hold with finger while drawing the paper from under the transfer.**
- 5. Smooth down with straight edge or hand working from center to edge.**
- 6. Wash face of transfer and dry with a clean cloth.**

DO NOT APPLY IN FREEZING WEATHER

ALLOW TO DRY FOR 24 HOURS

THE F-K CO. BOX 747, CAPE CORAL, FLORIDA

a div. of R.G. South Industries